TANK SPARES	
S.NO	**Description**
1	Casting NRV - 1/2"
2	Aluminium NRV - 1/2,3/4 ,1.1/2 inch
3	Aluminium NRV Washer - 1/2,3/4 ,1.1/2 inch
4	Aluminium NRV spring - 1/2,3/4 ,1.1/2 inch
5	Aluminium NRV stem - 1/2,3/4 ,1.1/2 inch
6	Aluminium NRV Nut - 1/2,3/4 ,1.1/2 inch
7	Aluminium NRV Cone Guide - 1/2,3/4 ,1.1/2 inch
8	1"VERTICAL NRV
9	Breather Assembly
10	Pressure Gauge - 150,200,200 KG
11	Pressure Switch with Valve & without Valve
12	Wheel Valve - 1/4"
13	Drain Cock - 3/8"
14	Plastic Wheel - 3"
15	Ermoto Cone Nut - 1/2" x 1/2"
16	V belt
17	Plastic oil Level Indicator
18	Aluminium oil Level Indicator
19	AIR COCK - 1/4,3/8
20	LOCAL SAFETY VALVE - 3/8"
21	L.G SAFETY VALVE -1/2,1/4,3/4,3/8 (ORDER)
22	BRASS WHEEL VALVE - 1/4 "
23	BRASS FERUL SET - 1/4"
24	DOUBLE SIDE WHEEL VALVE - 1/4
AFTER COOLER PIPE	
25	PIPE WITH ERMETO - 1.0HP ,1.5 HP,2.0 HP,STC200,STC300, STC500,SC50 ,SC100 ,SC150
26	2.0HP LOCAL AFTER COOLER PIPE
27	STC1000 FULL SET
28	SC150 FULL SET
29	SC150 TOPBLOCK SET
30	U PIPE + ERMETO
31	S PIPE + ERMETO
32	TC 50 HNU PIPE
33	TC 50 HNU PIPE 1070MM
34	TC 50 HNZ PIPE
35	TC 1000 270MM
36	TC 1000 300MM
37	TS10 HN PIIPE
38	TC 1000 C PIPE